
Meridian 1

Meridian 1

System installation procedures

Document Number: 553-3001-210
Document Release: Standard 13.00
Date: October 1997

© 1990, 1997
All rights reserved

Printed in the United States of America

Information is subject to change without notice. Northern Telecom reserves the right to make changes in design or components as progress in engineering and manufacturing may warrant. This equipment has been tested and found to comply with the limits for a Class A digital device pursuant to Part 15 of the FCC rules, and the radio interference regulations of Industry Canada. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses and can radiate radio frequency energy, and if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at their own expense.

SL-1 and Meridian 1 are trademarks of Northern Telecom.

Revision history

January 29, 1990

Standard, release 1.0.

February 28, 1990

Standard, release 2.0.

December 1, 1991

Standard, release 3.0. This document is reissued to include technical content updates. Due to the extent of the changes, revision bars are not used.

December 31, 1992

Standard, release 4.0. New information and changes to technical content are noted by revision bars in the margins.

April 1, 1993

Standard, release 5.0. Due to the extent of the changes, revision bars are not used.

August 1, 1993

Standard, release 6.0. New information and changes to technical content are noted by revision bars in the margins.

April 1, 1994

Standard, release 7.0. New information and changes to technical content are noted by revision bars in the margins.

December 1994

Standard, release 8.0. This document is reissued to include updated information on the Small systems Multi-Disk Unit (SMDU), option 51C, NTND01CA 12MB ICM card. Changes to technical content are noted by revision bars in the margins.

December 1994

Standard, release 9.0. Reissued for technical content.

July 1995

Standard, release 10.00. Reissued to include international information to create a global NTP, option 81, option 81C, and minor text and graphic changes. Changes to technical content are noted by revision bars in the margins.

December 1995

Standard, release 11.00. Reissued for technical content. Includes information on System 600/48 Power Plant.

August 1996

Standard, release 12.00. Reissued for technical content. Includes references to the new NT9D19 48 MB Call Processing Card and a new procedure to install software. Changes to technical content are noted by revision bars in the margins.

October 1997

Standard, release 13.00. Includes references to the new 68060 NT5D10 Call Processor and NT5D61 IODU/C cards. Changes are noted by revision bars in the margins.

Contents

Introduction	1
About this document	1
References	1
Meridian 1 equipment	4
Equipment handling precautions	6
Unloading equipment	6
Power equipment	6
Circuit cards	7
Data disks	8
Cable routing guidelines	9
Initial Meridian 1 installation	11
System installation procedures	12
Preparing equipment for installation	15
Placing the fourth module on a column	23
Positioning and leveling equipment	29
Installing overhead cable tray kits	35
Installing AC power	37
Safety ground/protective earth and logic return wiring	38
Installation procedures	42

Installing DC power	47
External DC power equipment	48
Safety ground/protective earth and logic return wiring	51
PDU connections	54
Installation procedures	58
 Planning and designating the Modular Distribution Frame (MDF)	 69
BIX installation and designation	71
Backplane cable expansion	76
Krone cross connect system (UK)	76
 Installing PFTUs	 85
Installation procedure	88
Connecting trunks and telephones	90
Installing QUA6 PFTUs (UK installations)	91
 Configuring the system monitor	 93
Configuring the NT8D22 System Monitor	93
Cabling the NT8D22 System Monitor	97
Installing the NT7D15 System Monitor	104
 Connecting a system terminal (or modem)	 107
Options 51C, 61C, 81, and 81C terminal and modem connections	116
Configuring the Motorola 28.8 Data/Fax Modem	125
Configuring an A0381391 UDS FastTalk modem	128
Connecting a modem to an SDI port	130
Connecting a modem to a switch box and CPSI and SDI ports ...	130
 Cabling common equipment	 135
System option 61	136
System option 61C	139
System option 71	147
System option 81	157
System option 81C	173

Cabling network loops	191
NT8D04 Superloop Network Card	192
QPC414 Network Card	201
QPC414 Network Card connected to an NT5K11 EEPE module ..	208
Cabling lines and trunks	217
I/O panel connections	221
Connecting lines and trunks	226
Powering up the system and initial loading	315
Preparing for power-up	315
Connecting power for AC-powered systems	318
Connecting power for DC-powered systems	319
Installing new system software	321
Options 61C and 81C	321
Performing acceptance tests	331
Module power supply test	331
Blower unit and thermal sensor test	333
Sysload test	335
System terminal and system monitor test	337
PFTU test	338
Disk drive unit test	338
Installing earthquake bracing	341
Installing seismic bracing	342
Selecting the kit	342
Drilling the floor	345
Installing anchor plates	346
Installing rods	348
Positioning and leveling the system	350
Installing non-seismic bracing	355
Selecting the kit	355
Non-seismic anchor kit installation instructions	356

Configuring remote peripheral equipment	359
Installing RPE	364
RPE option switch settings	378
Performing acceptance tests	384
Testing equipment	384
Testing transmission quality	385
Locating span line faults	385
 Adding a module to a column	 389
Adding a module to the base of a column	390
Adding a module between two other modules	395
Adding a module to the top of a column	401
 Appendix A: NT0R72, NT6D82, QBL12, QBL15, QCA13	 411
Installing an NT6D82 Power System	411
Installing a QBL12 distribution box	412
Installing a QBL15 power system	417
Installing a QCA13 power plant	432
Installing safety ground/protective earth and logic return wiring	433
Connecting the PDU	440
Connecting the NT8D22 system monitor	450
 Appendix B: NT7D10 PDU connections	 455
 Appendix C: Backplane cabling in NT8D11 and NT8D37 modules	 467
I/O panel connections	472
Connecting lines and trunks	473
Backplane cable expansion	494
NT8D11 CE/PE Modules	494
NT8D37 IPE Modules	497

Appendix D: Customer supplied power equipment	501
System grounding and interconnection to Meridian 1	501
Power feed distribution	505
Recommended signal connections to Meridian 1 System Monitor	505
Alarm signal	505
Trip signal	505
Recommended features on customer supplied power equipment	506
Current and Voltage Meters	506
Visual and Audible Alarms	506
Batteries	507
UPS or Auxiliary Generator	507
Appendix E: List of terms	509